

ROCK-BLOCK MOISTURE BARRIER SYSTEM

- TREATMENT FOR MOVING CRACKS AND JOINTS

1) Prepare crack, joint or popout. 4) Fill almost to grade with elastomeric joint fill

2) Prime side walls only with neat ROCK-BLOCK liquids.

3) Insert backer rod in compression

5) Install finish system up to, but not over the treated joint

